
Whirlpool


CABINET PARTS



CABINET PARTS

| Illus. No. | | DESCRIPTION | | |
|--|---|---|--|--|
| 1 | W10137645 67005395 W10165418 | Literature Parts Owners Manual Energy Tag Tech Sheet | | |
| 2 | | Cabinet (Not a Servicable Part) | | |
| 3 | 67001130 67001131 | Plug, Button (3) White Black | | |
| 4 5 6 | 67005064 67006118 12627302 | Label, Fill Tube Roller Assembly Clip, Grille | | |
| 7 8 | 67006642 67006611 | Pin, Center Hinge Bolt, Adjusting (Rear) | | |
| 9 10 11 12 13 14 | 67006521 67001098 67006380 67006473 A3076901 67006303 | Screw Cover, Fill Tube Screw Screw (8) Plug, Button Screw (3) | | |
| 15 16 17 | 67006960 67007043 67003868 | Hinge, Center White Black Foot Brake (2) Cover, Corner | | |
| 18 19 20 21 | 67003484 67003485 12566604ED 12479901 67006564 | White Black Hinge, Top Plate, Cover Screw (8) Cover, Hinge | | |
| 22 | 67001014 67001012 | White Black Grille Assembly | | |
| 24 25 26 27 28 29 30 31 32 33 | 67006905 67006886 67006662 67006425 67007174 67001173 12575101ED 67003796 W10164397 67001067 67006737 B5759649 | (Includes Clips) White Black Screw Screw (9) Bracket, Foot Cover, Water Valve Cover, Unit Insulation, Sound Tube, Drain Clip, Drain Tube Screw Gasket | | |

REFRIGERATOR LINER PARTS



REFRIGERATOR LINER PARTS

For Model: GB9SHDXPQ12, GB9SHDXPB12, GB9SHDXPS12 (White) (Black) (Stainless Steel)


| Illus No. | | DESCRIPTION | | | |
|--------------|-----------|-------------------------------|--|--|--|
| 1 | | Liner (Not A | | | |
| • | | Serviceable Part) | | | |
| 2 | Y67003896 | Bracket, Control | | | |
| | | and Lights | | | |
| 3 | 67005190 | Overlay | | | |
| 4 | W10185244 | Housing, | | | |
| | | Electronic Control | | | |
| 5 | W10165748 | Board, Control | | | |
| 6 | C3680310 | Switch, Light | | | |
| 7 | 67003897 | Cover, Light | | | |
| 8 | 67003901 | Housing, Light | | | |
| 9 | A0282812 | , | | | |
| 10 | Y12570701 | Socket, Light (2) | | | |
| 11 | 67003900 | Insert, | | | |
| 40 | 0700000 | Damper Cover | | | |
| 12 | 67006602 | Screw (2) | | | |
| 13 | 67003899 | Cover, Damper | | | |
| 14 | 67006604 | Insulation | | | |
| 15 16 | W10127429 | Control, Damper Thermistor | | | |
| | 12002355 | | | | |
| 17 | M0310343 | Plug Button | | | |
| | | | | | |

Following Parts Not Illustrated

67004033 Harness, Controls (Refrigerator) (Includes # 16)

FREEZER LINER PARTS

For Model: GB9SHDXPQ12, GB9SHDXPB12, GB9SHDXPS12 (White) (Black) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER LINER PARTS

For Model: GB9SHDXPQ12, GB9SHDXPB12, GB9SHDXPS12 (White) (Black) (Stainless Steel)


| Illus. No. | Part No. | DESCRIPTION |
|---------------|------------------------|--------------------------------------|
| 1 | | Liner (Not A |
| 2 | 67001291 | Seviceable Part) Gasket, Foam (2) |
| 2 3 | 12002497 | Gear (2) |
| | | (Includes RH & LH) |
| 4 | 67003905 | Cover, Light |
| 5 | 67004067 | Shaft |
| 6 8 | Y12570701 67006473 | Socket, Light |
| 9 | A0282812 | Screw (8) Bulb, Light |
| 10 | 67001035 | Housing, Frz. Light |
| 11 | 67005871 | Cover, Evaporator |
| 12 | 67005822 | Screw (7) |
| 13 | | Bracket, Door |
| | W10122147 | Left |
| 4.4 | W10122148 | Right |
| 14 15 | 67003906 W10167028 | Housing, Lighting |
| 16 | 67005653 | Clip, Evap. Motor Switch, Light |
| 18 | 07003033 | Bracket, Basket |
| .0 | W10187668 | Left |
| | W10187667 | Right |
| 19 | W10120018 | Slide, Drawer (2) |
| 20 | 67003731 | Gasket, Bottom |
| 21 | W40400440 | Bracket, Slide |
| | W10128118 W10128119 | Left Right |
| 22 | W10126119 W10175909 | Cover, Fan Shroud |
| 23 | W10173303 | Shroud, Evap.Fan |
| 24 | 2169142 | Fan, Evaporator |
| 25 | W10121318 | Grommet (2) |
| 26 | 67003636 | Motor, Evaporator |
| 27 | D7753903 | Funnel, Drain |
| 28 | M0500703 | (Incl. # 28 & 29) Seal |
| 29 | B8381501 | Gasket |
| 30 | 12002355 | Thermistor |
| 31 | 67003924 | Cover, Thermistor |
| 32 | 67006406 | Screw (6) |
| 33 | 67006530 | Screw |

Following Parts Not Illustrated

67006095 Harness, Lights (Freezer)

REFRIGERATOR DOOR PARTS

For Model: GB9SHDXPQ12, GB9SHDXPB12, GB9SHDXPS12 (White) (Black) (Stainless Steel)




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR DOOR PARTS

| Illus No. | . Part No. | DESCRIPTION |
|--------------|----------------------|-------------------------------|
| 1 | | Refrigerator Door |
| ' | | (w/ Insulation) |
| | 67001138 | |
| | 67001136 | |
| | W10174588 | Stainless Steel |
| 2 | | Plug, Vent |
| | 10712401 | White |
| | 67004838 | Black |
| 3 | 67003819 | |
| 4 | 67001279 | Tray, Dairy |
| 5 | 67003777 | Bucket (2) |
| 6 | 67000604 | (Medium) |
| 6 7 | 67002684 | Nameplate Plug, Button (2) |
| , | 67001131 | Black |
| | 67001131 | White |
| 8 | 07001100 | Gasket, Door |
| _ | | Magnetic |
| | W10130148 | White |
| | 12683815B | Black |
| 9 | | Handle, Door |
| | 67002677 | White |
| | 67002679 | |
| 10 | 67006682 | Screw |
| 11 | 67002629 | Closure, Door White |
| | 67003638 67003639 | |
| 12 | 67003033 | Bucket (1) |
| 12 | 0700+12+ | (Short) |
| 13 | | Bushing |
| | 67004977 | White |
| | 67004978 | Black |
| 14 | 67002505 | Retainer, Door |
| 15 | 67006287 | Screw |
| 16 | 12574902 | Bin, Egg |
| 17 | | Stop, Door |
| | 67003779 | White |
| 40 | 67003780 | Black |
| 18 | 67002682 | Trim, Handle White |
| | 67002680 | |
| 19 | 67005626 | Caddy, Can |
| 20 | 67003778 | Bucket (2) |
| • • | | (Small) |
| | | |


FREEZER DOOR PARTS



FREEZER DOOR PARTS

| Illus | . Part | | | | | |
|---------|-----------|-----------------|--|--|--|--|
| No. No. | | DESCRIPTION | | | | |
| | | | | | | |
| 1 | | Freezer Door | | | | |
| | | (w/ Insulation) | | | | |
| | W10184159 | White | | | | |
| | W10184161 | Black | | | | |
| | W10177221 | Stainless Steel | | | | |
| 2 | | Handle, Door | | | | |
| | 67002677 | White | | | | |
| | 67002679 | | | | | |
| 3 | | Trim, Handle | | | | |
| | 67002682 | White | | | | |
| | 67002680 | Black | | | | |
| 4 | | Gasket, Door | | | | |
| | W10130150 | White | | | | |
| | 12683816B | Black | | | | |
| 5 | 67006682 | | | | | |
| 6 | | Plug, Vent (2) | | | | |
| | 10712401 | | | | | |
| | 67004838 | Black | | | | |


SHELF PARTS



SHELF PARTS

| Illus. | Part | | | | |
|----------|----------------------|-------------------------|--|--|--|
| No. | No. | DESCRIPTION | | | |
| | | | | | |
| 1 | 67002690 | Ladder, Side | | | |
| 2 | 67006400 | Screw (6) | | | |
| 3 | 67002689 | Ladder, Center | | | |
| 4 | 67006360 | Screw (2) | | | |
| 6 | 67002687 | Shelf, Meatkeeper | | | |
| 7 | 12204810 | Glass, Crisper | | | |
| 8 | 67004380 | Frame, Crisper | | | |
| 9 | 67002687 | Pan, Meatkeeper | | | |
| 10 | 12227101 | Knob, Control | | | |
| 11 | D7725402 | Tray, Ice Cube | | | |
| 12 | 67001057 | Rail, Center | | | |
| | | Crisper | | | |
| 13 | 8170554 | Brace, (2) | | | |
| | | Crisper Frame | | | |
| 14 | 10688093 | Trim, Crisper | | | |
| 15 | 67001928 | Pan, Crisper (2) | | | |
| 16 | 67004985 | Basket, Freezer | | | |
| | | (Upper) | | | |
| 17 | 12646501 | Rack, Ice | | | |
| 18 | 67004127 | Divider, | | | |
| 4.0 | .= | Upper Basket | | | |
| 19 | 67006608 | Screw | | | |
| 20 | 67006023 | Basket, Freezer | | | |
| 04 | 07000044 | (Lower) | | | |
| 21 | 67006644 | Divider, | | | |
| 22 | 10006404 | Lower Basket | | | |
| 22 | 12226401 | Seal, Crisper (2) | | | |
| 23 24 | 10481001 | Roller (4) | | | |
| 24 25 | 10972101 | Spacer, Rack | | | |
| 25 26 | 67002686 | Shelf, Glide (3) | | | |
| 26 27 | 67006908 67006692 | Screw (2) | | | |
| 28 | 12052502 | Screw (4) Rack, Wine | | | |
| 20 | 12002002 | Nack, Wille | | | |


UNIT PARTS



UNIT PARTS

| Illus | | DESCRIPTION | Illus | | DESCRIPTION | Illus. | Part | DESCRIPTION |
|--|---|--|--|---|---|--------|----------------------------|---|
| No. | No. | DESCRIPTION | No. | No. | DESCRIPTION | No. | No. | DESCRIPTION |
| 1 2 3 4 | 67006914 67006425 | Blade, Fan Basepan Screw (2) | 19 20 21 22 | 67001133 10623002 | Tube, Discharge Tray, Drip Clip, Evaporator Evaporator | | | arts Not Illustrated Parts Not Included |
| 5 6 7 | 67004954 W10130129 W10119856 | Compressor | 23 | 67001083 | Dam Right Side Left Side Motor, Fan | | | Valve, Access (1/4") Valve, Access |
| 8 9 10 11 12 13 14 15 16 | 61004743 67002135 67005562 W10174592 61003210 W10165425 W10137529 | Drain Pan Grommet (3) Evaporator Heater Capacitor Overload/Relay (Capacitor Incl.) Gasket Thermostat Grommet (4) Shroud, Condenser | 25 26 27 28 29 30 31 32 33 34 | 10428101 13060201 B2150504 10547003 67004953 W10169124 67006432 67006573 67006737 | Clip, Heater Harness, Unit Includes Cord Drier (Service) Clip, Drier Bracket, Fan Grommet (3) Screw (2) Screw (4) | | 978028 978029 978030 | (5/16") Valve, Access (3/8") Valve, Access (1/2") Valve, Access (5/8") Valve, Access (3/4") Valve, Access (3/16") |
| 18 | | Condenser | 35 36 37 | 67005491 67005149 | Block, Condenser | REFR | RIGER <i>A</i> | 5.00 Ozs. (R-134A) |

ICEMAKER PARTS



ICEMAKER PARTS

For Model: GB9SHDXPQ12, GB9SHDXPB12, GB9SHDXPS12 (White) (Black) (Stainless Steel)

| Illus No | | DESCRIPTION |
|-------------|--------------------|---------------------------|
| 1 | | Mold & Heater |
| | | Assembly |
| | | (Not Available |
| 2 | 67004000 | Order D7824706Q) |
| 2 3 4 | 67004028 628356 | Arm, Shutoff Cup, Fill |
| 3 1 | 627843 | Ejector |
| 5 | 2182124 | Ice Stripper |
| 6 | 2195914 | Support & Motor |
| Ū | 2100011 | Assembly |
| 7 | 2315522 | Retainer, |
| | | Thermostat |
| 8 | | Thermostat |
| | | (Not Available |
| | | Order D7824706Q) |
| 9 | 681249 | Screw (2) |
| 10 | 67001255 | Pan, Ice |
| 11 | 67004101 | Bracket, Tube |
| 12 | 67006504 | Support |
| 12 | 67006531 | Valve, Water Inlet |
| 13 | A3223101 | Insert, Tube |
| 14 | B5705307 | Tubing, Plastic |
| 15 | W10146389 | Harness, Icemaker |
| 16 | 625910 | Bracket |
| 17 | 67006662 | Screw |
| 18 | 67004710 | Cover |
| 19 | | Module Assembly |
| | | (Not Available |
| | | Order D7824706Q) |
| 20 | 67006287 | Screw |
| 21 | 67005603 | Funnel, Fill |
| 400 | W40400540 | Tube |
| 100 | W10122519 | Complete Icemaker |
| | | |
| | | |

Following Parts Not Illustrated

18001005 Icemaker Install Kit

OPTIONAL PARTS (NOT INCLUDED)

For Model: GB9SHDXPQ12, GB9SHDXPS12 (White) (Black) (Stainless Steel)

Illus. Part

No. No. DESCRIPTION

PAINT, TOUCH-UP (1/2oz.)

72017 White 72032 Black

PAINT, PRESSURIZED SPRAY (12 oz.)

*350930 White *350939 Black *350942 Primer, White

*Important: The spray paint is not to be used where the paint may make contact with the door gaskets. Illus. Part No. No.

No. DESCRIPTION

PAINT, BULK (1 qt.)

799344 White (Uncut) 799340 Black (Uncut)

Miscellaneous

212643 Sealer, Gum

(4 Feet)

479502 Tape, Vinyl (3/4 x 108")

505587 Sealer, Mastic

(1 Qt.)

503695 Cork, Sealer (1/4 Pound)

542638 Grease, Silicone

(1/2 Oz.)

542639 Cement, Alumilastic

(1–1/4 Oz.)

799833 Kit, Evaporator

Repair

(Aluminum Epoxy) 833938 Kit, Terminal

Connector

Illus. Part

No. No. DESCRIPTION

TORX SCREW WRENCH

1117510 Torx Key

ACCESSORIES

4396920 Cleaner, Stainless Steel